

STOP
+
Ⓢ

CAUTION: It is advisable to disconnect the negative battery cable for 3 minutes before beginning installation, to avoid unintended air bag deployment. Note and record any anti-theft radio codes prior to disconnecting.

VEHICLE PREPARATION



1. Remove the overhead console by removing six (6) Torx-20 screws behind the sunglasses, business card holders, and dome light area. **FIGURE 1.** *NOTE: The console for a truck with a sunroof and other trim levels and cab configurations use **FIGURE 2.** Disconnect dome light harness from front of overhead console.*

2. Release pivot points in sunglass compartment and remove from overhead console. **FIGURE 3.** Remove sunglass compartment deployment dampener by depressing both tabs and pushing dampener through side of console. **FIGURE 4**

3. For **07 TUNDRA**, drill a 7/8" or 22mm hole in right corner as shown in **FIGURE 5.** Carefully de-burr the hole. For **08 SEQUOIA**, cut tabs and remove knockout. **FIGURE 6**

4. Dislodge the white 12-pin vehicle connector from the holding clips shown in **FIGURE 7.**



