

2005-2009 Toyota Tacoma Overhead Console Fuse test

* does your cruise control work?

* do you brake lights work?

* does your dome light work?

The 10 amp IGI #2 fuse controls several other components including the dome light, cruise control, and brake lights. If these are working but the compass is dim, intermittent, or dead then the control module has gone bad.

www.autoclockrepair.com